


1. Device volume

Before using the IDTECH UniMag reader, turn the Media Volume of your device up to maximum level:

Please refer to your smart phone's user manual for more information on adjusting your device's volume levels.



2. Plug in card reader

Insert the ID TECH UniMag card reader into your device's headphone jack as shown below:



3. Configure your card reader in AprivaPay

- When signed into AprivaPay, tap your device's MENU button, and then tap Settings.
- Under Card Reader, tap Enable.
- Under Card reader, tap No Card reader selected.
- Tap ID TECH UniMag.

